



Description

When changing a lower pressure P140 to a higher pressure unit, the bonnet and adjustment screw must be changed as well.

5"-7" up to 1-2 psi spring ranges use;

Bonnet **604-291-000** Adjustment Screw **648-581-000**

2-4 psi up to 4-5 psi spring ranges use;

Bonnet **604-292-000** Adjustment Screw **648-581-001**



Note: More than just a spring change is needed.